

PARKING STATEMENT FOR FOUR WHEELER C.T.S.NO. 195 A/2				
B/LG. FLOOR	FLAT NO.	TOTAL TENEMENTS REQUIRED	PARKING PROVIDED	PARKING LOCATION
1 st FLOOR	101-102-106	107	107	BASEMENT
2 nd FLOOR	201-202-205-206	46	46	BASEMENT
3 rd FLOOR	301-302-305-306	46	46	BASEMENT
4 th FLOOR	401-402-405-406	46	46	BASEMENT
5 th FLOOR	501-502-505-506	46	46	BASEMENT
6 th FLOOR	601-602-605-606	46	46	BASEMENT
7 th FLOOR	701-702-705-706	46	46	BASEMENT
8 th FLOOR	801-802-805-806	46	46	BASEMENT
9 th FLOOR	901-902-905-906	46	46	BASEMENT
10 th FLOOR	1001-1002-1005-1006	46	46	BASEMENT
11 th FLOOR	1101-1102-1105-1106	46	46	BASEMENT
12 th FLOOR	1201-1202-1205-1206	46	46	BASEMENT
13 th FLOOR	1301-1302-1305-1306	46	46	BASEMENT
14 th FLOOR	1401-1402-1405-1406	46	46	BASEMENT
15 th FLOOR	1501-1502-1505-1506	46	46	BASEMENT
16 th FLOOR	1601-1602-1605-1606	46	46	BASEMENT
17 th FLOOR	1701-1702-1705-1706	46	46	BASEMENT
18 th FLOOR	1801-1802-1805-1806	46	46	BASEMENT
19 th FLOOR	1901-1902-1905-1906	46	46	BASEMENT
20 th FLOOR	2001-2002-2005-2006	46	46	BASEMENT
21 st FLOOR	2101-2102-2105-2106	46	46	BASEMENT
22 nd FLOOR	2201-2202-2205-2206	46	46	BASEMENT
23 rd FLOOR	2301-2302-2305-2306	46	46	BASEMENT
24 th FLOOR	2401-2402-2405-2406	46	46	BASEMENT
25 th FLOOR	2501-2502-2505-2506	46	46	BASEMENT
26 th FLOOR	2601-2602-2605-2606	46	46	BASEMENT
27 th FLOOR	2701-2702-2705-2706	46	46	BASEMENT
28 th FLOOR	2801-2802-2805-2806	46	46	BASEMENT
29 th FLOOR	2901-2902-2905-2906	46	46	BASEMENT
30 th FLOOR	3001-3002-3005-3006	46	46	BASEMENT
31 st FLOOR	3101-3102-3105-3106	46	46	BASEMENT
32 nd FLOOR	3201-3202-3205-3206	46	46	BASEMENT
33 rd FLOOR	3301-3302-3305-3306	46	46	BASEMENT
34 th FLOOR	3401-3402-3405-3406	46	46	BASEMENT
35 th FLOOR	3501-3502-3505-3506	46	46	BASEMENT
36 th FLOOR	3601-3602-3605-3606	46	46	BASEMENT
37 th FLOOR	3701-3702-3705-3706	46	46	BASEMENT
38 th FLOOR	3801-3802-3805-3806	46	46	BASEMENT
39 th FLOOR	3901-3902-3905-3906	46	46	BASEMENT
40 th FLOOR	4001-4002-4005-4006	46	46	BASEMENT
41 st FLOOR	4101-4102-4105-4106	46	46	BASEMENT
42 nd FLOOR	4201-4202-4205-4206	46	46	BASEMENT
43 rd FLOOR	4301-4302-4305-4306	46	46	BASEMENT
44 th FLOOR	4401-4402-4405-4406	46	46	BASEMENT
45 th FLOOR	4501-4502-4505-4506	46	46	BASEMENT
46 th FLOOR	4601-4602-4605-4606	46	46	BASEMENT
47 th FLOOR	4701-4702-4705-4706	46	46	BASEMENT
48 th FLOOR	4801-4802-4805-4806	46	46	BASEMENT
49 th FLOOR	4901-4902-4905-4906	46	46	BASEMENT
50 th FLOOR	5001-5002-5005-5006	46	46	BASEMENT
51 st FLOOR	5101-5102-5105-5106	46	46	BASEMENT
52 nd FLOOR	5201-5202-5205-5206	46	46	BASEMENT
53 rd FLOOR	5301-5302-5305-5306	46	46	BASEMENT
54 th FLOOR	5401-5402-5405-5406	46	46	BASEMENT
55 th FLOOR	5501-5502-5505-5506	46	46	BASEMENT
56 th FLOOR	5601-5602-5605-5606	46	46	BASEMENT
57 th FLOOR	5701-5702-5705-5706	46	46	BASEMENT
58 th FLOOR	5801-5802-5805-5806	46	46	BASEMENT
59 th FLOOR	5901-5902-5905-5906	46	46	BASEMENT
60 th FLOOR	6001-6002-6005-6006	46	46	BASEMENT
61 st FLOOR	6101-6102-6105-6106	46	46	BASEMENT
62 nd FLOOR	6201-6202-6205-6206	46	46	BASEMENT
63 rd FLOOR	6301-6302-6305-6306	46	46	BASEMENT
64 th FLOOR	6401-6402-6405-6406	46	46	BASEMENT
65 th FLOOR	6501-6502-6505-6506	46	46	BASEMENT
66 th FLOOR	6601-6602-6605-6606	46	46	BASEMENT
67 th FLOOR	6701-6702-6705-6706	46	46	BASEMENT
68 th FLOOR	6801-6802-6805-6806	46	46	BASEMENT
69 th FLOOR	6901-6902-6905-6906	46	46	BASEMENT
70 th FLOOR	7001-7002-7005-7006	46	46	BASEMENT
71 st FLOOR	7101-7102-7105-7106	46	46	BASEMENT
72 nd FLOOR	7201-7202-7205-7206	46	46	BASEMENT
73 rd FLOOR	7301-7302-7305-7306	46	46	BASEMENT
74 th FLOOR	7401-7402-7405-7406	46	46	BASEMENT
75 th FLOOR	7501-7502-7505-7506	46	46	BASEMENT
76 th FLOOR	7601-7602-7605-7606	46	46	BASEMENT
77 th FLOOR	7701-7702-7705-7706	46	46	BASEMENT
78 th FLOOR	7801-7802-7805-7806	46	46	BASEMENT
79 th FLOOR	7901-7902-7905-7906	46	46	BASEMENT
80 th FLOOR	8001-8002-8005-8006	46	46	BASEMENT
81 st FLOOR	8101-8102-8105-8106	46	46	BASEMENT
82 nd FLOOR	8201-8202-8205-8206	46	46	BASEMENT
83 rd FLOOR	8301-8302-8305-8306	46	46	BASEMENT
84 th FLOOR	8401-8402-8405-8406	46	46	BASEMENT
85 th FLOOR	8501-8502-8505-8506	46	46	BASEMENT
86 th FLOOR	8601-8602-8605-8606	46	46	BASEMENT
87 th FLOOR	8701-8702-8705-8706	46	46	BASEMENT
88 th FLOOR	8801-8802-8805-8806	46	46	BASEMENT
89 th FLOOR	8901-8902-8905-8906	46	46	BASEMENT
90 th FLOOR	9001-9002-9005-9006	46	46	BASEMENT
91 st FLOOR	9101-9102-9105-9106	46	46	BASEMENT
92 nd FLOOR	9201-9202-9205-9206	46	46	BASEMENT
93 rd FLOOR	9301-9302-9305-9306	46	46	BASEMENT
94 th FLOOR	9401-9402-9405-9406	46	46	BASEMENT
95 th FLOOR	9501-9502-9505-9506	46	46	BASEMENT
96 th FLOOR	9601-9602-9605-9606	46	46	BASEMENT
97 th FLOOR	9701-9702-9705-9706	46	46	BASEMENT
98 th FLOOR	9801-9802-9805-9806	46	46	BASEMENT
99 th FLOOR	9901-9902-9905-9906	46	46	BASEMENT
100 th FLOOR	10001-10002-10005-10006	46	46	BASEMENT
101 st FLOOR	10101-10102-10105-10106	46	46	BASEMENT
102 nd FLOOR	10201-10202-10205-10206	46	46	BASEMENT
103 rd FLOOR	10301-10302-10305-10306	46	46	BASEMENT
104 th FLOOR	10401-10402-10405-10406	46	46	BASEMENT
105 th FLOOR	10501-10502-10505-10506	46	46	BASEMENT
106 th FLOOR	10601-10602-10605-10606	46	46	BASEMENT
107 th FLOOR	10701-10702-10705-10706	46	46	BASEMENT
108 th FLOOR	10801-10802-10805-10806	46	46	BASEMENT
109 th FLOOR	10901-10902-10905-10906	46	46	BASEMENT
110 th FLOOR	11001-11002-11005-11006	46	46	BASEMENT
111 st FLOOR	11101-11102-11105-11106	46	46	BASEMENT
112 nd FLOOR	11201-11202-11205-11206	46	46	BASEMENT
113 rd FLOOR	11301-11302-11305-11306	46	46	BASEMENT
114 th FLOOR	11401-11402-11405-11406	46	46	BASEMENT
115 th FLOOR	11501-11502-11505-11506	46	46	BASEMENT
116 th FLOOR	11601-11602-11605-11606	46	46	BASEMENT
117 th FLOOR	11701-11702-11705-11706	46	46	BASEMENT
118 th FLOOR	11801-11802-11805-11806	46	46	BASEMENT
119 th FLOOR	11901-11902-11905-11906	46	46	BASEMENT
120 th FLOOR	12001-12002-12005-12006	46	46	BASEMENT
121 st FLOOR	12101-12102-12105-12106	46	46	BASEMENT
122 nd FLOOR	12201-12202-12205-12206	46	46	BASEMENT
123 rd FLOOR	12301-12302-12305-12306	46	46	BASEMENT
124 th FLOOR	12401-12402-12405-12406	46	46	BASEMENT
125 th FLOOR	12501-12502-12505-12506	46	46	BASEMENT
126 th FLOOR	12601-12602-12605-12606	46	46	BASEMENT
127 th FLOOR	12701-12702-12705-12706	46	46	BASEMENT
128 th FLOOR	12801-12802-12805-12806	46	46	BASEMENT
129 th FLOOR	12901-12902-12905-12906	46	46	BASEMENT
130 th FLOOR	13001-13002-13005-13006	46	46	BASEMENT
131 st FLOOR	13101-13102-13105-13106	46	46	BASEMENT
132 nd FLOOR	13201-13202-13205-13206	46	46	BASEMENT
133 rd FLOOR	13301-13302-13305-13306	46	46	BASEMENT
134 th FLOOR	13401-13402-13405-13406	46	46	BASEMENT
135 th FLOOR	13501-13502-13505-13506	46	46	BASEMENT
136 th FLOOR	13601-13602-13605-13606	46	46	BASEMENT
137 th FLOOR	13701-13702-13705-13706	46	46	BASEMENT
138 th FLOOR	13801-13802-13805-13806	46	46	BASEMENT
139 th FLOOR	13901-13902-13905-13906	46	46	BASEMENT
140 th FLOOR	14001-14002-14005-14006	46	46	BASEMENT
141 st FLOOR	14101-14102-14105-14106	46	46	BASEMENT
142 nd FLOOR	14201-14202-14205-14206	46	46	BASEMENT
143 rd FLOOR	14301-14302-14305-14306	46	46	BASEMENT
144 th FLOOR	14401-14402-14405-14406	46	46	BASEMENT
145 th FLOOR	14501-14502-14505-14506	46	46	BASEMENT
146 th FLOOR	14601-14602-14605-14606	46	46	BASEMENT
147 th FLOOR	14701-14702-14705-14706	46	46	BASEMENT
148 th FLOOR	14801-14802-14805-14806	46	46	BASEMENT
149 th FLOOR	14901-14902-14905-14906	46	46	BASEMENT
150 th FLOOR	15001-15002-15005-15006	46	46	BASEMENT
151 st FLOOR	15101-15102-15105-15106	46	46	BASEMENT
152 nd FLOOR	15201-15202-15205-15206	46	46	BASEMENT
153 rd FLOOR	15301-15302-15305-15306	46	46	BASEMENT
154 th FLOOR	15401-15402-15405-15406	46	46	BASEMENT
155 th FLOOR	15501-15502-15505-15506	46	46	BASEMENT
156 th FLOOR	15601-15602-15605-15606	46	46	BASEMENT
157 th FLOOR	15701-15702-15705-15706	46	46	BASEMENT
158 th FLOOR	15801-15802-15805-15806	46	46	BASEMENT
159 th FLOOR	15901-15902-15905-15906	46	46	BASEMENT
160 th FLOOR	16001-16002-16005-16006	46	46	BASEMENT
161 st FLOOR	16101-16102-16105-16106	46	46	BASEMENT
162 nd FLOOR	16201-16202-16205-16206	46	46	BASEMENT
163 rd FLOOR	16301-16302-16305-16306	46	46	BASEMENT
164 th FLOOR	16401-16402-16405-16406	46	46	BASEMENT
165 th FLOOR	16501-16502-16505-16506	46	46	BASEMENT
166 th FLOOR	16601-16602-16605-16606	46	46	BASEMENT
167 th FLOOR	16701-16702-16705-16706	46	46	BASEMENT
168 th FLOOR	16801-16802-16805-16806	46	46	BASEMENT
169 th FLOOR	16901-16902-16905-16906	46	46	BASEMENT
170 th FLOOR	17001-17002-17005-17006	46	46	BASEMENT
171 st FLOOR	17101-17102-17105-17106	46	46	BASEMENT
172 nd FLOOR	17201-17202-17205-17206	46	46	BASEMENT
173 rd FLOOR	17301-17302-17305-17306	46	46	BASEMENT
174 th FLOOR	17401-17402-17405-17406	46	46	BASEMENT
175 th FLOOR	17501-17502-17505-17506	46	46	BASEMENT
176 th FLOOR	17601-17602-17605-17606	46	46	BASEMENT
177 th FLOOR	17701-17702-17705-17706	46	46	BASEMENT
178 th FLOOR	17801-			